





Detailed Information for Phones

Web interface of the STARFACE	Menu "Configuration"	Menu "Phones"	Button "Edit"
			

This documentation describes which detailed information can be read out within a single telephone account on the STARFACE and which configuration options are available at this point.

Details

Extended Settings

Device type:

snom760

Functionality:

Phone

Phone name:

1972.snom760

Password:

rxv0hldrJJh0nIE2

Random Password

Emergency Call

Location:

Default

Autoprovisioning

Last provisioning:

Oct 31, 2018 10:27:46 AM

Last known device IP:

MAC address:

00041371C42F

Applied server address:

Firmware version:

8.9.3.60.0

Overwrite device config:

☒

Device Type: In this drop-down menu you can see which predefined STARFACE device profiles have been automatically selected for this telephone account. Via the list entry "new ..." a new device type can be created.

Functionality: In this drop-down menu you can configure what functionality this account should cover. The following options are available:

Name	Description
Phone	This setting is selected for normal phones.
Fax	This setting must be selected for fax machines connected via ATA adapters, e.g. if an analog Patton or Grandstream Gateway is being used.
IPC	This setting is provided for terminal devices of IPC's trading communication systems. Unlike with SIP telephones, the terminal device's fixed IP address is specified in the Restrict to IP field instead of a password.

Phone name: The telephone name stored here is the "username" of the SIP account, so to speak, and should be selected so that it is as meaningful and unique as possible. The automatically generated telephone name always includes an abbreviation which applies to a note on the telephone model and can be applied without any problems as a general rule.



Note: It is recommended to use a telephone name at least 5 digits long.

Password: The password should be selected so that it is as long and complicated as possible, and we recommend using a password generated using the button "Random Password".

Emergency Call: If the telephone account is not operated in the same area code as STARFACE, another location must be selected here, because an emergency call is always connected to the respective location's local area network and within its prefix range. Additional emergency call locations are created and configured in the line range.

Overwrite device config: If this function is activated, changes to the SIP account made above are automatically transferred to the telephone's/terminal device's first line/connection. But the following aspects must be taken into account during this process:

- Autoprovisioning must be active on STARFACE.
- This function only takes effect when the device's HTTP access is not protected by access data other than that specified by the system.
- The automatic configuration always only affects the first line of a SIP telephone. If the telephone is already registered e.g. on another telephone system via this first line, this configuration is overwritten.

- If the existing SIP account is not on the first line of the SIP telephone, its settings are not changed by automatic overwriting. The account is also created on line 1. This can lead to problems, because the telephone will try to register on the server using both lines.



Note: The setting is not saved permanently, but only affects this one configuration process. The next time the configuration view is opened, the field is active again by default.

In the tab "Extended Settings" the following options are available:

Details	Extended Settings
Extended Configuration	
NAT:	Default ▼
Codecs:	g722,alaw,ulaw
Door Intercom	
<input type="radio"/> Enable <input checked="" type="radio"/> Disable	
Camera URL:	<input type="text"/> <input type="button" value="Test Connection"/>
DTMF:	<input type="text"/>

NAT: The **Default** setting means that the global STARFACE setting is adopted from the Network section (see also "[Configuring the STARFACE Network Settings](#)"). It is recommended to always use **Default** or **Yes** here, particularly if the telephone/terminal device is outside of the local network.

Codecs: A codec ensures the conversion of analog (voice) information to digital data and vice versa (encoding and decoding).

The G.711 codecs **alaw** and **ulaw** are used as default settings for most telephone models. The G.711 codecs have a good voice quality and a very short delay time of just 2 ms, but they require a (relatively) high bit rate of up to 84 kbit/s.

The broadband codec G.722 (high-definition voice) offers a far higher voice quality than G.711 with its frequency range of 50 to 7000 Hz at a lower transmission rate (64 kbit/s). Many of the telephones supported by STARFACE also work with G.722.

It is possible to explicitly assign one or more codecs to a telephone account; several codecs are entered and separated by commas. For example:

g722,alaw,ulaw

But it should be ensured beforehand that the respective telephone model supports the codecs and that use of the codecs is activated on the telephone itself.

Generally, STARFACE supports the use of the following codecs:

- alaw
- ulaw
- g722
- g726
- gsm
- h63
- h263p

Door Intercom: Here, information on whether the telephone account is a door intercom or not can be activated or deactivated.

Camera URL: If it is a door intercom with camera, the IP address and the file path for accessing the door camera's image data can be stored here.

The camera image is displayed in the Callmanager of the STARFACE web interface and in the STARFACE UCC client. Some telephones (e.g. Yealink T48G) are also shared for use of a camera image.

Examples of camera URLs:

http://IP address of the door intercom/jpg/image.jpg for Baudisch

http://IP address of the camera enu/camera320x240.jpg for 2N EntryCom IP



Note: When integrating a door intercom, please also always observe the manufacturer's documentation.

DTMF: The DTMF code for opening the door using the telephone keys is stored here. Additionally, in the Call Manager a link is assigned with the key code via which the door can be opened at the mere click of a mouse.



Note: The "Opening Doors using DTMF" functional feature can be used independently of the use of a door camera and also with door intercoms which do not have a camera.

The button "Test Connection" can be used to test the configuration for the door station.